
Beeper Settings

Beeper Volume

Parameter # 0x8C

To select a decode beep volume, scan the appropriate bar code.



Low
(0x02)



Medium
(0x01)



***High**
(0x00)