

Reset


To reset the scanner and apply parameters from the configuration file, scan the following bar code.



Reset

Reset Factory Defaults

To reset the scanner to factory defaults, scan the following bar code. This rebuilds the configuration file from program memory.



Reset Factory Defaults