

Symbol CS3000/CS3070 – Set Date and Time

1. Set Date and Time

Each scanner comes pre-configured with the current date and time set, based on your school's time zone. After Daylight Saving Time changes or if scanner settings have been modified, you may need to reset the date and time on the unit to ensure accuracy.

Set Date

Scan the Set Date bar code, then scan six numeric digits in the format **mmddy** from the **Numeric Bar Codes** section



Set Date

Set Time

Scan the Set Time bar code, then scan four numeric digits in the format **hhmm** from the **Numeric Bar Codes** section, representing the time according to the 24-hour clock. For example, to set the time to 3:07 in the afternoon, scan 1, 5, 0, 7



Set Time

Cancel Date and Time Setting

Scan the Cancel Set Date/Time bar code to cancel the date and time settings



Cancel Set Date/Time

2. Numeric Bar Codes

Numeric bar codes for date/time settings and Bluetooth pairing



0



1



2



3



4



5



6



7



8



9



Enter